



## **2890R – Heated Glove with Rechargeable Lithium-Ion Battery User Instructions**

### **WARNING**

- Lithium-ion batteries can be permanently damaged by cold-charging. To extend the life of the battery, never charge the battery in or just after using in extreme cold conditions. Always allow the battery to come up to room temperature before charging.
- Always store the battery in a cool, dry place
- Prior to use, check to ensure that all wires, electrical connectors, and batteries are free from damage. DO NOT USE batteries if wires, electrical connectors, and/or batteries are damaged.

### **Using the Battery**

1. Unzip the battery pouch on the back of the glove and locate the USB connection.
2. Plug the USB connector into the USB port on the battery. The green lights on the battery window should illuminate to indicate the battery life remaining. The glove power button will illuminate from Green to Blue to Red to indicate that the battery is connected.
3. Tuck battery and USB wire into the battery pouch on the back of the glove and zip closed.
4. The battery can be turned off by pressing and holding the button below the battery life indicator for 3 seconds. To turn the battery back on, press and release this button.

### **Charging the Battery**

1. You can use the USB to mini-USB charging cord included with your battery for charging
2. To charge, connect the mini USB cable connector to the mini-USB port on the battery.
3. Connect the USB cable connector to a USB charging source.
4. While charging, the green battery life indicator lights on the battery will flash
5. Charging is complete when all 4 indicator lights are illuminated

### **Using the Heated Glove**

1. After installing the battery in the glove for use, push down and hold on the glove power button for 3 seconds. The power button will illuminate.
2. To change the temperature setting, press the power button and release. The indicator will cycle through 3 power settings:
  - a. Green – Low
  - b. Blue – Medium
  - c. Red – High
3. To power the glove OFF, press and hold the glove power button for 3 seconds. The power button should no longer be illuminated.